

# Easy UPS 3M

## Parallel Maintenance Bypass Panel

### Installation

E3MBPAR60K200H

09/2019



# Legal Information

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this guide are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a non-exclusive and personal license to consult it on an "as is" basis. Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.



Go to <http://www.productinfo.schneider-electric.com/portals/ui/easyups3m/> for translations.

Rendez-vous sur <http://www.productinfo.schneider-electric.com/portals/ui/easyups3m/> pour accéder aux traductions.

Vaya a <http://www.productinfo.schneider-electric.com/portals/ui/easyups3m/> para obtener las traducciones.

Gehe zu <http://www.productinfo.schneider-electric.com/portals/ui/easyups3m/> für Übersetzungen.

Vai a <http://www.productinfo.schneider-electric.com/portals/ui/easyups3m/> per le traduzioni.

Vá para <http://www.productinfo.schneider-electric.com/portals/ui/easyups3m/> para obter as traduções.

Перейдите по ссылке <http://www.productinfo.schneider-electric.com/portals/ui/easyups3m/> для просмотра переводов.

前往 <http://www.productinfo.schneider-electric.com/portals/ui/easyups3m/> 查看译文。

前往 <http://www.productinfo.schneider-electric.com/portals/ui/easyups3m/> 查看譯文。

# Table of Contents

Important Safety Instructions — SAVE THESE	
INSTRUCTIONS .....	5
Electromagnetic Compatibility .....	6
Safety Precautions .....	6
Electrical Safety.....	8
Overview of UPS System with Parallel Maintenance Bypass	
Panel.....	10
Specifications .....	12
Recommended Cable Sizes .....	12
Recommended Upstream Protection.....	13
Recommended Bolt and Lug Sizes .....	13
Torque Specifications.....	14
Parallel Maintenance Bypass Panel Weights and Dimensions.....	14
Clearance .....	14
Environment.....	14
Installation Procedure .....	15
Mount the Parallel Maintenance Bypass Panel to the Wall .....	15
Prepare the Parallel Maintenance Bypass Panel for Cables .....	16
Connect the Power Cables.....	18
Connect the Signal Cables .....	18



# Important Safety Instructions — SAVE THESE INSTRUCTIONS

Read these instructions carefully and look at the equipment to become familiar with it before trying to install, operate, service or maintain it. The following safety messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety message indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages with this symbol to avoid possible injury or death.

## DANGER

**DANGER** indicates a hazardous situation which, if not avoided, **will result in death or serious injury**.

**Failure to follow these instructions will result in death or serious injury.**

## WARNING

**WARNING** indicates a hazardous situation which, if not avoided, **could result in death or serious injury**.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

## CAUTION

**CAUTION** indicates a hazardous situation which, if not avoided, **could result in minor or moderate injury**.

**Failure to follow these instructions can result in injury or equipment damage.**

## NOTICE

**NOTICE** is used to address practices not related to physical injury. The safety alert symbol shall not be used with this type of safety message.

**Failure to follow these instructions can result in equipment damage.**

## Please Note

Electrical equipment should only be installed, operated, serviced, and maintained by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

## Electromagnetic Compatibility

### **NOTICE**

#### **RISK OF ELECTROMAGNETIC DISTURBANCE**

This is a product Category C3 according to IEC 62040-2. This is a product for commercial and industrial applications in the second environment - installation restrictions or additional measures may be needed to prevent disturbances. The second environment includes all commercial, light industry, and industrial locations other than residential, commercial, and light industrial premises directly connected without intermediate transformer to a public low-voltage mains supply. The installation and cabling must follow the electromagnetic compatibility rules, e.g.:

- the segregation of cables,
- the use of shielded or special cables when relevant,
- the use of grounded metallic cable tray and supports.

**Failure to follow these instructions can result in equipment damage.**

## Safety Precautions

### **DANGER**

#### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

Read all instructions in the installation manual before installing or working on this product.

**Failure to follow these instructions will result in death or serious injury.**

### **DANGER**

#### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

Do not install the product until all construction work has been completed and the installation room has been cleaned.

**Failure to follow these instructions will result in death or serious injury.**

### **DANGER**

#### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

The product must be installed according to the specifications and requirements as defined by Schneider Electric. It concerns in particular the external and internal protections (upstream breakers, battery breakers, cabling, etc.) and environmental requirements. No responsibility is assumed by Schneider Electric if these requirements are not respected.

**Failure to follow these instructions will result in death or serious injury.**

## **DANGER**

### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

The UPS system must be installed according to local and national regulations. Install the UPS according to:

- IEC 60364 (including 60364-4-41 - protection against electric shock, 60364-4-42 - protection against thermal effect, and 60364-4-43 - protection against overcurrent), **or**
- NEC NFPA 70, **or**
- Canadian Electrical Code (C22.1, Part 1)

depending on which one of the standards apply in your local area.

**Failure to follow these instructions will result in death or serious injury.**

## **DANGER**

### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

- Install the product in a temperature controlled indoor environment free of conductive contaminants and humidity.
- Install the product on a non-flammable, level and solid surface (e.g. concrete) that can support the weight of the system.

**Failure to follow these instructions will result in death or serious injury.**

## **DANGER**

### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

The product is not designed for and must therefore not be installed in the following unusual operating environments:

- Damaging fumes
- Explosive mixtures of dust or gases, corrosive gases, or conductive or radiant heat from other sources
- Moisture, abrasive dust, steam or in an excessively damp environment
- Fungus, insects, vermin
- Salt-laden air or contaminated cooling refrigerant
- Pollution degree higher than 2 according to IEC 60664-1
- Exposure to abnormal vibrations, shocks, and tilting
- Exposure to direct sunlight, heat sources, or strong electromagnetic fields

**Failure to follow these instructions will result in death or serious injury.**

## **DANGER**

### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

Do not drill or cut holes for cables or conduits with the gland plates installed and do not drill or cut holes in close proximity to the UPS.

**Failure to follow these instructions will result in death or serious injury.**

## **WARNING**

### **HAZARD OF ARC FLASH**

Do not make mechanical changes to the product (including removal of cabinet parts or drilling/cutting of holes) that are not described in the installation manual.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

**NOTICE****RISK OF OVERHEATING**


Respect the space requirements around the product and do not cover the ventilation openings when the product is in operation.

**Failure to follow these instructions can result in equipment damage.**

**Electrical Safety****⚠ DANGER****HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

- Electrical equipment must be installed, operated, serviced, and maintained only by qualified personnel.
- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices.
- Turn off all power supplying the UPS system before working on or inside the equipment.
- Before working on the UPS system, check for hazardous voltage between all terminals including the protective earth.
- The UPS contains an internal energy source. Hazardous voltage can be present even when disconnected from the mains supply. Before installing or servicing the UPS system, ensure that the units are OFF and that mains and batteries are disconnected. Wait five minutes before opening the UPS to allow the capacitors to discharge.
- The UPS must be properly earthed/grounded and due to a high leakage current, the earthing/grounding conductor must be connected first.

**Failure to follow these instructions will result in death or serious injury.**

**Distribution-Related Backfeed**

The upstream disconnection switchgear must be suitable for disconnection purposes. Before working on the upstream supply, the MBB must be locked in the open position using the built-in lockout function.

When installing the parallel maintenance bypass panel, warning labels must be posted on the load side of all upstream disconnection devices. The labels must be supplied by the user, displaying the following text (or equivalent in a language which is acceptable in the country in which the UPS system is installed):





**DANGER**

**HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**


Risk of Voltage Backfeed. Before working on this circuit: Isolate the UPS and check for hazardous voltage between all terminals including the protective earth.

885-95958\_REV03

# Overview of UPS System with Parallel Maintenance Bypass Panel


## Single Mains Systems

UIB	Unit input breaker
SSIB	Static switch input breaker
UOB	Unit output breaker
MBB	Maintenance bypass breaker
SIB	System isolation breaker



## Dual Mains Systems

UIB	Unit input breaker
SSIB	Static switch input breaker
UOB	Unit output breaker
MBB	Maintenance bypass breaker
SIB	System isolation breaker



# Specifications

## NOTICE

### HAZARD OF EQUIPMENT DAMAGE

Refer to the UPS installation manual for detailed specifications for the UPS system.

**Failure to follow these instructions can result in equipment damage.**

## Recommended Cable Sizes

## ⚠ DANGER

### HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

All wiring must comply with all applicable national and/or electrical codes. The maximum allowable cable size is 185 mm<sup>2</sup>.

**Failure to follow these instructions will result in death or serious injury.**

Cable sizes in this manual are based on table B.52.5 of IEC 60364-5-52 with the following assertions:

- 90 °C conductors
- An ambient temperature of 30 °C
- Use of copper conductors
- Installation method C

PE size is based on table 54.2 of IEC 60364-4-54.

If the ambient temperature is greater than 30 °C, larger conductors are to be used in accordance with the correction factors of the IEC.

**NOTE:** Refer to the UPS installation manual for UPS input cable sizes.

	Cable	3+0 Parallel Capacity			2+0 Parallel Capacity 2+1 Parallel Redundant			1+0 Single 1+1 Parallel Redundant		
		Per Phase (mm <sup>2</sup> )	Neutral (mm <sup>2</sup> )	PE (mm <sup>2</sup> )	Per Phase (mm <sup>2</sup> )	Neutral (mm <sup>2</sup> )	PE (mm <sup>2</sup> )	Per Phase (mm <sup>2</sup> )	Neutral (mm <sup>2</sup> )	PE (mm <sup>2</sup> )
60 kVA	UPS output	25	2x25	16	25	2x25	16	25	2x25	16
	Input (single mains)/ bypass (dual mains)	2x70	4x70	70	95	2x95	50	25	2x25	16
	Load	2x70	4x70	70	95	2x95	50	25	2x25	16
80 kVA	UPS output	50	2x50	25	50	2x50	25	50	2x50	25
	Input (single mains)/ bypass (dual mains)	2x95	4x95	95	120	2x120	70	50	2x50	25
	Load	2x95	4x95	95	120	2x120	70	50	2x50	25
100 kVA	UPS output	70	2x70	35	70	2x70	35	70	2x70	35
	Input (single mains)/ bypass (dual mains)	4x50	4x95	120	2x70	4x70	70	70	2x70	35
	Load	4x50	4x95	120	2x70	2x150 or 4x70	70	70	2x70	35
120 kVA	UPS output	95	2x70	50	95	2x70	50	95	2x70	50
	Input (single mains)/ bypass (dual mains)	4x70	4x95	150	2x95	4x70	95	95	120 or 2x70	50

	Cable	3+0 Parallel Capacity			2+0 Parallel Capacity 2+1 Parallel Redundant			1+0 Single 1+1 Parallel Redundant		
		Per Phase (mm <sup>2</sup> )	Neutral (mm <sup>2</sup> )	PE (mm <sup>2</sup> )	Per Phase (mm <sup>2</sup> )	Neutral (mm <sup>2</sup> )	PE (mm <sup>2</sup> )	Per Phase (mm <sup>2</sup> )	Neutral (mm <sup>2</sup> )	PE (mm <sup>2</sup> )
	Load	4x70	4x95	150	2x95	2x150 or 4x70	95	95	120 or 2x70	50
160 kVA	UPS output	–	–	–	120	120	70	120	120	70
	Input (single mains)/bypass (dual mains)	–	–	–	4x50	4x70	120	120	120	70
	Load	–	–	–	2x120 or 4x50	2x150 or 4x70	120	120	120	70
200 kVA	UPS output	–	–	–	2x70	2x70	70	2x70	2x70	70
	Input (single mains)/bypass (dual mains)	–	–	–	4x70	4x70	185	150 or 2x70	150 or 2x70	70
	Load	–	–	–	2x185 or 4x70	2x185 or 4x70	185	150 or 2x70	150 or 2x70	70

## Recommended Upstream Protection

	3+0 Parallel Capacity					2+0 Parallel Capacity 2+1 Parallel Redundant					1+0 Single 1+1 Parallel Redundant				
	Breaker	Io	Ir	I <sub>sd</sub>	Tr	Breaker	Io	Ir	I <sub>sd</sub>	Tr	Breaker	Io	Ir	I <sub>sd</sub>	Tr
60 kVA	NSX400N mic2.3	320	320	1.5-10	–	NSX250N mic2.3	200	200	1.5-10	–	NSX100N TM100D	–	100	–	–
80 kVA	NSX400N mic2.3	400	400	1.5-10	–	NSX400N mic2.3	280	280	1.5-10	–	NSX160N TM160D	–	144	–	–
100 kVA	NSX630N mic2.3	500	500	1.5-10	–	NSX400N mic2.3	320	320	1.5-10	–	NSX160N TM160D	–	160	–	–
120 kVA	NSX630N mic2.3	500	500	1.5-10	–	NSX400N mic2.3	400	400	1.5-10	–	NSX250N mic2.3	250	250	1.5-10	–
160 kVA	–	–	–	–	–	NSX630N mic2.3	500	500	1.5-10	–	NSX400N mic2.3	320	320	1.5-10	–
200 kVA	–	–	–	–	–	NSX630N mic2.3	630	630	1.5-10	–	NSX400N mic2.3	400	400	1.5-10	–

## Recommended Bolt and Lug Sizes

Cable Size	Terminal Bolt Diameter	Cable Lug Type
16 mm <sup>2</sup>	M10	KST TLK16-10
25 mm <sup>2</sup>	M10	KST TLK25-10
35 mm <sup>2</sup>	M10	KST TLK35-10
50 mm <sup>2</sup>	M10	KST TLK50-10
70 mm <sup>2</sup>	M10	KST TLK70-10
95 mm <sup>2</sup>	M10	KST TLK95-10
120 mm <sup>2</sup>	M10	KST TLK120-10
150 mm <sup>2</sup>	M10	KST TLK150-10
185 mm <sup>2</sup>	M10	KST TLK185-10

Torque Specifications


Bolt Size	Torque
M10	30 Nm

Parallel Maintenance Bypass Panel Weights and Dimensions

	Weight kg	Height mm	Width mm	Depth mm
Parallel maintenance bypass panel E3MBPAR60K200H	62	1000	700	320

Clearance

**NOTE:** Clearance dimensions are published for airflow and service access only. Consult with the local safety codes and standards for additional requirements in your local area.



Environment

	Operating	Storage
Temperature	0 °C to 40 °C	-25 °C to 55 °C
Relative humidity	0 – 95% non-condensing	0 – 95% non-condensing
Protection class	IP20	
Color	RAL 9003	

# Installation Procedure

1. *Mount the Parallel Maintenance Bypass Panel to the Wall, page 15.*
2. *Prepare the Parallel Maintenance Bypass Panel for Cables, page 16.*
3. *Connect the Power Cables, page 18.*
4. *Connect the Signal Cables, page 18.*

## Mount the Parallel Maintenance Bypass Panel to the Wall


### ⚠ CAUTION

#### RISK OF INJURY OR EQUIPMENT DAMAGE

- Mount the maintenance bypass panel to a wall or a rack that is structurally sound and able to support the weight of the unit.
- Use appropriate hardware for the wall/rack type.


**Failure to follow these instructions can result in injury or equipment damage.**

1. Measure and mark the four mounting hole locations on the wall.



2. Drill holes in each of the four marked locations and mount the anchor bolts.

3. Remove the screws and open the inner door.



4. Mount the parallel maintenance bypass panel to the wall.

## Prepare the Parallel Maintenance Bypass Panel for Cables

### **⚠ DANGER**



#### **HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

Do not drill or punch holes with the gland plates installed and do not drill or punch holes in close proximity to the parallel maintenance bypass panel.

**Failure to follow these instructions will result in death or serious injury.**



1. Remove the top and bottom gland plates.



**Top of Parallel Maintenance Bypass Panel****Bottom of Parallel Maintenance Bypass Panel**

2. Drill or punch holes for cables or grommets in the gland plates.
3. Install grommets (if applicable) and refit the gland plates.

**⚠ DANGER****HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**


Ensure that there are no sharp edges that can damage the cables.

**Failure to follow these instructions will result in death or serious injury.**

**Top of Parallel Maintenance Bypass Panel****Bottom of Parallel Maintenance Bypass Panel**

## Connect the Power Cables

1. Connect the PE cable to the PE busbar.




2. Connect the input/bypass cables to the maintenance bypass switch MBB.
3. Connect the UPS output cables to the system isolation breaker SIB.
4. Connect the load cables.
5. Fasten the cables with cable ties to the cable reliefs.


## Connect the Signal Cables

**NOTE:** Route the signal cables separately from the power cables.


1. Remove the plastic cover of the maintenance bypass switch MBB to get access to the AUX switches.



2. Connect signal cables (not supplied) from the three AUX switches in the maintenance bypass switch MBB to the UPSs.



3. Fasten the signal cables to the cable reliefs.



4. Close the inner door and fasten with screws.
5. Close the front door.

Schneider Electric  
35 rue Joseph Monier  
92500 Rueil Malmaison  
France

+ 33 (0) 1 41 29 70 00



As standards, specifications, and design change from time to time,  
please ask for confirmation of the information given in this publication.

© 2019 – 2019 Schneider Electric. All rights reserved.

990-5994A-001