

LG Digital Signage

(MONITOR SIGNAGE)

43UL3J-B*	65UL3J-B*
50UL3J-B*	75UL3J-B*
55UL3J-B*	86UL3J-B*

۲




Image shown in manual may vary depending on model.

Depending on country
Depending on model

Unpacking

۲

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and item.

()







- Worldwide : www.lg.com/id-manual
- SuperSign : http://partner.lge.com

You can download more detailed information on our website by searching the model number provided on the cover page. For the power supply and power consumption, refer to the label attached to the product.

۲

۲





۲


۲

۲

- **NOTE** Image shown may vary depending on model. All connection cables & devices shown in the picture are not included along

with the product.





۲

۲







- **O NOTE** Image shown may vary depending on model . All connection cables & devices shown

in the picture are not included along with the product.


ARC (Audio Return Channel)

- An external audio device that supports SIMPLINK and ARC must be connected using HDMI IN/ARC port
- When connected with a high-speed HDMI cable, the external audio device that supports ARC outputs SPDIF audio without additional audio cable and supports the SIMPLINK function.

NOTE -

- Some USB Hubs may not work, if a USB device connected using a USB Hub is not detected, connect it to the USB port on the TV directly
- Connect the external power source if your USB is needed.






۲


Image shown may vary depending on

Mage shown may vary depending on model . All connection cables & devices shown in the picture are not included along with the product.



۲








Image shown may vary depending on model.





IN002043